

Preset Button Index

Preset Button Order

Preset buttons do not have a specific number assigned to them. Instead, they display one of the presets within the current bank. Pressing the **Bank Up** and **Bank Down** buttons changes the bank, which in turn changes which presets are assigned to the preset buttons. (For a description of presets and banks, please refer to the [Buttons and Pages](#) section).

When a new bank is selected, the Mastermind has to decide which preset is assigned to each preset button. It examines the buttons in a specific order, and assigns the first preset in the bank to the first preset button it finds. The second preset button it finds gets the second preset in the bank, etc. The order in which it scans through the buttons depends on your device:

Mastermind GT - starts in the upper left corner, and goes from left to right. When it reaches the end of a row, it goes down one row and starts at the left side of the row, scanning to the right again.

Mastermind LT - starts in the lower left corner (the 1 button), then scans to the right. When it finishes that row, it goes up to the Bank Down button, and scans to the right again. Finally, the Function button is scanned.

Mastermind PBC/10 - starts in the lower left corner (the 1 button), then scans to the right. When it finishes that row, it goes up to the Switches button, and scans to the right again. Finally, the Loops button is scanned.

Mastermind PBC/6X - starts in the lower left corner (the 1 button), then scans to the right. When it finishes that row, it goes up to the Functions button, and scans to the right again.

Order Reassignment with Preset Index

If for some reason, you want to change the order of how presets are assigned to buttons, you can do this with the **Preset Index** setting found on Preset buttons. By default, these are all set to 0, which means that the standard order (as described above) is used. If you assign different Preset

Index numbers to the buttons, the presets will be assigned in that order - number 1 will receive the first preset in the bank, number 2 will receive the second preset in the bank, etc.

If two buttons have the same Preset Index, the buttons will be assigned different presets using the standard order to decide which one receives which preset. Skipping Preset Index numbers has no effect - if, for example, you assign preset indexes 1, 10, 57, 93 and 100 to your preset buttons, those buttons will be assigned presets 1, 2, 3, 4 and 5 within your bank.

If you need to assign a button that accesses a specific preset regardless of which bank you're in, you can use an [IA button](#) with a System / Preset [action](#).

For more information on Preset buttons and the Preset Index setting, please see Mastering the [Mastermind Episode 6, Button Editing part 1](#), and [Episode 7, Advanced Button Editing](#)

Revision #2

Created 16 June 2021 03:15:44 by rjmeditor

Updated 16 September 2022 23:42:34 by RJM Music