

# Introduction

- [About the Editor Software](#)
- [System Requirements](#)
- [Installation - Mac](#)
- [Installation - PC](#)

# About the Editor Software

The Mastermind GT is a very advanced MIDI controller with extensive capabilities and an LCD over every button. The Mastermind PBC is a pedalboard based audio switcher that uses the same "brains" as the Mastermind GT, giving it similar MIDI capabilities. And the Mastermind LT is a small, low cost MIDI controller using the same core as the Mastermind PBC. All of these devices are able to connect to a PC or Mac using a standard USB connection and communicate with our editor software.

The editor software is able to edit settings and transfer those settings to and from the GT, LT and PBC. On the Mastermind GT, the editor permits much faster editing using a familiar user interface. The editor does the same for the Mastermind LT and PBC, but also unlocks the full power of these units, allowing the user perform far more editing tasks than is possible using the on-board editing.

# System Requirements

The Mastermind GT, LT and PBC editor can run on a Windows PC or a Macintosh running OS X.

## **Windows:**

- Windows 7 or later, 32 or 64-bit
- 2GB RAM
- One free USB port
- A USB cable that ends in a USB B connector, which is the square type that most printers use.

## **Mac OS X:**

- OS X 10.13 (High Sierra) or later, 64-bit only
- 2GB RAM
- One free USB port
- A USB cable that ends in a USB B connector, which is the square type that most printers use.

# Installation - Mac

To install on a Mac OS X system, first download the file from the [Downloads page](#) on the [RJM Music website](#). Before downloading, make sure the correct product is selected in the bar above the list of releases.

*Important note: The editor version needs to match the first two numbers of your product's firmware version. For example, If you have firmware version 4.6.1, the editor needs to be version 4.6.x. In general, it's best to have the latest firmware and editor version. Your Mastermind's firmware version is displayed in bottom right corner of the main LCD display for 2 seconds on power up.*

Double-click the .dmg file that was downloaded, and it will open up a window showing the Editor app and a link to the Applications folder. Drag the editor app file to the Applications folder to install.

[MacInstall.png](#)

To run, open up your Applications folder, where you'll find the MMGTEditor or MastermindEditor file. Double click the file and the editor will start up.

# Installation - PC

To install on a PC system, first download the file from the [Downloads page](#) on the [RJM Music website](#). Before downloading, make sure the correct product type is selected in the bar above the list of releases.

*Important note: The editor version needs to match the first two numbers of your product's firmware version. For example, If you have firmware version 4.6.1, the editor needs to be version 4.6.x. In general, it's best to have the latest firmware and editor version. Your Mastermind's firmware version is displayed in bottom right corner of the main LCD display for 2 seconds on power up.*

Double-click the .zip file that was downloaded, and it will open up a window showing the editor MSI (installer) file. On some systems, the .zip file will automatically be extracted, in which case you will already have a MSI installer file. Double click this file to start the installation process. Follow the prompts to complete installation.

To run, go to the Start Menu and look for "MMGTEditor" or "MMEditor" under "All Programs" and select the editor app within that folder.