


Expression Pedal Settings Blocks

On the [Globals Tab](#), you can specify up to 128 Expression Pedal Settings Blocks. Each block is a separate expression pedal configuration that can be recalled at any time.

To edit a settings block, simply double click it in the Expression Pedal section of the [Globals Tab](#). The [Expression Pedal Edit Page](#) will pop up, allowing you to configure that block. Each one can be named to help identify it.



To use a settings block, execute a System / ExpPedal [action](#). This is typically done by assigning that action to an IA button, but it can also be executed in other ways such as [Preset Actions](#) or an [expression pedal position switch](#).

This action below, when placed on a button, will set expression pedal #1 to the settings in Exp Pedal 5 when the button is turned on. When the button is turned off, the expression pedal will return to its global settings.

IA Actions

System / ExpPedal #1 off:Global on:5

New Action Action Type: System

Add CC Action Subtype: ExpPedal

Remove Action ExpPd: 1

Off Value: Global

On Value: 5

Revision #2

Created 16 June 2021 03:15:42 by rjmeditor

Updated 16 September 2022 23:08:42 by RJM Music