

# IA Cycle

IA buttons have an **IA Cycle** setting that allows them to become IA Cycle buttons. When enabled, the button can be configured to switch between up to 4 different button states, each with a different name (on the Mastermind GT) and color.

When **IA Cycle** is checked, the **IA Actions** box at the bottom of the window gets a second tab labeled **IA Cycle Steps**. Clicking on this tab displays a box for each of the four steps. In each step's box, you can select a name and color for the step.

The screenshot shows the 'IA Cycle Steps' tab in a software interface. It contains four panels, each representing a step in the cycle. Each panel has a 'Name' text input field and a 'Color' dropdown menu. The settings for each step are as follows:

Step	Name	Color
Step 1	Fuzz	Aqua
Step 2	Screamer	Yellow
Step 3	Shred	Red
Step 4	Step 4	Blue

To use these steps, switch back to the **IA Actions** tab. Insert [Actions](#) in the list like you normally would, but use a **System / Step** action as a divider between steps. (You can press the **Add Step** button to quickly add a Step action to the end of the list.) You should not put a Step action at the end of the list - it would be interpreted as the beginning of another step. If you put more than three Step actions in the list, that will result in more than the maximum of four steps. Any step after the fourth is ignored.

The screenshot shows the 'IA Actions' tab in a software interface. It features a list of actions on the left, a 'New Action' button, and configuration options on the right. The list of actions includes:

- Mini Effect Giz:Loop 1 / CC Toggle #88 off:0 on:127
- Mini Effect Giz:Loop 3 / CC Toggle #90 off:0 on:0
- System / Step
- Mini Effect Giz:Loop 1 / CC Toggle #88 off:0 on:0
- Mini Effect Giz:Loop 2 / CC Toggle #89 off:0 on:127
- System / Step
- Mini Effect Giz:Loop 2 / CC Toggle #89 off:0 on:0
- Mini Effect Giz:Loop 3 / CC Toggle #90 off:0 on:127

On the right, there are buttons for 'New Action', 'Add CC Action', 'Add Step', and 'Remove Action'. Below these buttons are two dropdown menus: 'Action Type' (set to 'None') and 'Device' (set to 'Mini Effect Giz').

When the button is pressed, the button will advance to the next step and execute all of the actions in the list until it reaches the next Step action or the end of the list. Once the end of the action list is reached, the next button press will move back to the beginning of the action list.

When using an IA Cycle button, only the On values of each action are used - the Off values are ignored.

The images on this page show an example configuration that switches between pedals in the first three loops of a Mini Effect Gizmo. Pressing the IA cycle button switches from one pedal loop to the next. Only three steps are defined in the action list, so the name and color settings for the fourth step are ignored. Note that each step turns on one loop and turns off the previously selected loop. This prevents the case where more than one loop is on at the same time.

## IA Cycle Menu (GT Only)

On the Mastermind GT, there's an additional option that appears to the right of the IA Cycle checkbox simply called **Menu**. Checking this changes the behavior of the IA Cycle button. When checked, pressing the button pops up a menu in the GT buttons, with each button representing a cycle step. This allows you to see all of your cycle steps at the same time, and select from them with a single button press.

***For more information about IA Cycle buttons, please see [Mastering the Mastermind episode 13, IA Cycle Buttons](#)***

---

Revision #4

Created 16 June 2021 03:10:06 by rjmeditor

Updated 5 August 2022 00:26:04 by RJM Music